



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting




Issue 3

TL260 LDV Maxus Van 2005 - 2007

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Angle Brackets	E	12	M10 x 35 Bolts, 2 Nuts & 12 S/P Washers
C	1	Coupling Spacer	F	12	M10 x 25 Flat Washers

1. Remove the towing eye from the chassis member. (This is not refitted with the towbar.)
2. Using Item E with Item F loosely bolt Item A to existing fixing points in each chassis member.
3. Using Item E with Item F loosely bolt Item B to existing fixing points in each chassis member and to Item A.
4. Using item D with Item C bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
5. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.



Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed